

Blades Tow Right Inc
Wireless Light System Guide To Operations
RC-1

1. Plug the transmitter into your vehicles 4 pin connector
2. Place the unit with the 3/4" LED on the left side of the case on the left side of the vehicle, place the other unit on the right side of the vehicle.
3. Turn on both units using the rocker switch on the opposite side of the 3/4" light. The rocker switch will illuminate with a red LED.
4. Test the markers, left and right turn signals, and brake lights.

You cannot overcharge the battery in the light bar, so keep the bar on the charger when not in use. The batteries will resist developing a memory so you do not have to discharge them all the way. However, they must be charged on a regular basis to prevent them discharging to a very low voltage level.

If you have further questions, please call 800-205-3232.

The transmitter and receivers are serialized together and will only work with another transmitter or bar that are programmed with the same serial number. If you own more than 1 of the Blades Tow Right wireless light bars, make sure to keep the transmitter and light bar sets together.

If either the transmitter or light bar is lost or stolen, no other transmitter or light bar will work with the existing equipment. Only the company or person who purchased the light bar originally can order a replacement transmitter or light bar.

Please make sure to register your product. In the case of a lost or stolen transmitter or light bar, the information is needed to verify proper ownership and to replace the missing part.

Your 4 way truck socket should be wired as pictured below:

