

Blades Tow Right Wireless Light Bar Monitor Kit Guide To Operations

Turn on your wireless light bar before you plug in your monitor kit.

Plug the power jack into the back of the monitor kit, the other end into a 12V power source.

The battery indicator LEDs show you your battery strength.

All 3 LEDs means you have over 12.3V.

2 LEDs mean you have between 11.4V and 12.2V

1 LED means you have between 10.5V and 11.3V

No LED's mean your battery is below 10.5 volts and should be charged as soon as possible.

If the RED LED on the right side lights up, a 96db alarm will also sound. This means that your light bar is turned off, is below 3V or has gotten out of range of the monitor kit (possibly left behind or fallen off of the vehicle).

There is an approximate 8 second delay before the light and alarm come on. This is to make sure that some outside interference did not cause a temporary delay in the signal.



If you have any questions, please call 800-205-3232